Instructions For the Fastime 5 Stopwatch: 30 lap memory, Repeating countdown timer, pacer,alarm and time of day functions

Stopwatch mode:

A B C	Event Timing:	Split Timing:
	**C** – Start **C** – Stop (time Out) **C** – Continue **C** – Stop **A** - Reset	Top display shows previous lap time to last split. Middle display shows cumulative lap time. Bottom display shows current cumulative running time. **C** –Start **A** – Split **C** – Stop **A** - Reset

Memory Recall: Press **B** anytime to recall memory.
1st display shows fastest lap number and time. Press **B** again for slowest lap details
Press **B** each split time to show split times starting from the last split. Each display shows the split number, the lap time and cumulative time.
Press **MODE** to return to current running time

Press **MODE** button to move to Repeating Countdown Timers (9hr 59m 59sec) display:

To set the timer press and hold **A** until required digit flashes. Press **C** to change the digit. Press **B** to exit the setting.T2 starts when T1 ends.

Press **MODE** button to move to Pacer display:

Press **A** to set the pacer (from 10 to 320 per minute). Press **C** to start/stop the pacer

Press **MODE** button to move to Time of Day/date/alarm display:

To set time of day,date, alarm, Press and hold **A** until digits flash. Press **A** to choose digits to change. Press **C** to change the digits. Press **MODE** to exit setting

When the battery symbol appears replace the CR2032 battery: Unscrew the stopwatch back, replace battery Ensure that the triangular contact is in the triangular slot under the battery contact. Rescrew the battery contact and press all 4 buttons ABCD to perform a power reset. Rescrew back cover.

To save battery life, press buttons A and C at the same time. Hold for 3 seconds then release button A. The display will go blank. Press and hold any button to restart.

To vary the display contrast: Press and hold the MODE button until the display changes and the top digits flash. Press A or B buttons to vary the brightness/Contrast. The default is 13.